



Atid Co., Ltd.

AT388 User guide

AT388 Product User guide

Moon-Cheol Song

2017-09-04



AT388 User guide

AT388 Product User guide


Company

Atid Co., Ltd.

Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1
----------	------------	--------	-----------------	------	------------	------	------

Revision History

Version	Revised Date	Revised Reason	Revised Contents	Writer
V0.1	2017-09-04	Draft	Issue Draft	MoonCheol Song

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

Contents


Contents	3
1 Before Beginning	5
2 Product Overview	5
3 Strength of Product	6
4 H/W Specification	7
5 Product Composition	9
5.1 Product Composition	9
5.2 Composition of Each Product's Part	10
5.3 Function of Each Button	15
5.4 Configuration and operation of the Lamp	16
5.5 Screen Composition	17
5.5.1 State Display Section	17
5.5.2 Message Output Section	17
6 Basic Function of Device	18
6.1 Basic Function of Device	18
6.1.1 Scan Mode	18
6.1.2 Scan configuration Menu	18
6.1.3 System Configuration	19
6.2 Power ON and OFF	19
6.2.1 Power ON	19
6.2.2 Power OFF	20
6.3 Barcode Data Reading(Barcode Scan)	20
6.4 RFID Tag Data Reading(RFID Scan)	20
6.5 Scan Configuration	21
6.6 System Configuration	21
7 Settings & Changes	22
7.1 Scan Configuration	22
7.1.1 "1. View data"	22
7.1.2 "2. Upload data"	22
7.1.3 "3. Erase data"	22



AT388 User guide

AT388 Product User guide				Company	Atid Co., Ltd.		
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

7.1.4	"4. Data space"	23
7.1.5	"5. Comm & Mode"	23
7.1.6	"6. Poweroff Time"	23
7.1.7	"7. Network Setup"	24
7.1.7.1	"1. Show Info"	24
7.1.7.2	"2. Host Pairing"	24
7.1.7.3	"3. DHCP Mode"	25
7.1.7.4	"4. Paired Mode"	26
7.1.7.5	"5. Manual Setup"	26
7.2	System Configuration	27
7.2.1	"1. Symbol Setup"	27
7.2.2	"2. OP Mode"	27
7.2.3	"3. Comm & Mode"	28
7.2.4	"4. Data Format"	30
7.2.5	"5. System Setup"	32
7.2.6	"6. Factory Reset"	34
7.2.7	"7. Exit"	34
8	WiFi Connection and Setup	35
8.1	Preparations	35
8.2	WiFi SSID and Password Setup	35
8.3	Verifying the Data Transfer using WiFi	38
9	Bluetooth Connection setting	41
9.1	Windows 7 Environment	41
9.2	Windows 8 or Windows 10 Environment	45
10	Firmware Update	48
10.1	Preparation for Firmware	48
10.2	Firmware Update Start	48
11	Warranty and Technical Supports	52

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

1 Before Beginning,


The objective of user guide is to pass the basic contents related with AT388's maintenance and smooth uses.

User guide inclusive of text, images, logos, product name may not be distributed, modified, displayed, reproduced (in whole or in part) without the prior written permission of ATID CO.LTD Furthermore, the described contents in this document are subject to change without notice for improving or maintaining the product and we inform the user that some material can be different with the described contents due to the firmware changes of product.

Ownership of text, images, logos, product name in user guide is included in writer and some parts of text, images, logos, product name in the user guide were borrowed for user`s understanding at random. if there is a legal restriction such as a copyright law, it will be re-distributed after adjustment

2 Product Overview


AT388 is both subminiature barcode and RFID reader which can grasp with just one hand. As the device that meets the basic function for industrial product such as IP65 in water & dust test and 1.2 m drop specification, it can take an active as data collector in the various kinds of part in medicine, stock and product management and logistics shipping/tracking, access control. 1D/2D Barcode, UHF/HF RFID Tag information can be collected by just one AT388 and collected data can transfer to the HOST PC or Smart Phone by using Bluetooth or USB or Wireless LAN through Remote process / real time process / batch process mode. This device is designed to handle the data by the equipment which has the Windows, Android, iOS as an operating system.

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

3 Strength of Product

AT388 is the smallest product among the existing RFID Barcode Scanner-Reader product

- Its device as durable industrial PDA meets IP65 standard for the dust & water proof and 1.2m drop to concrete.
- Apply Honeywell N3680 Barcode module, fast and accurate support for Barcode data collection.
- UHF RFID Tag can be read and written quickly since Impinj R2000 module is installed in the product
- In case of that HF RFID module is installed, Various HF RFID tag can be read and written.
- Mode of Remote Process and Batch Process and Real Time Process can work for device
- It device can be connected with PC and charged up itself through USB Cable.
- It can be charged up without exclusive adapter through normal smartphone charger
- Read data through LCD Display can be directly checked.
- Battery changes is easily available and its device can change the battery in case of battery shortage while using it.
- Exclusive charging package for only battery charging will be offered (Option: To be Offered in the near future)

		AT388 User guide					
All That Identification		AT388 Product User guide			Company	Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

4 H/W Specification

Performance Characteristics

Processor	ARM7 Core
Support Operating System	Windows, Android, iOS(BLE or iAP Option)
Memory	1Mbit (512Kbyte able to use)
Display	1.3 inch LCD & LED Indicator
Weight	270g(without Battery 210g)
Operation Temperature	-20~40°C
Storage Temperature	-30~70°C
Humidity	95% non-condensing
Drop specification	1.2M Drop to concrete
Dust & Water Proof	IP65

Physical Characteristics

Audio	Buzzer
Standard I/O Port	Bluetooth 4.0, Micro USB
Notification	LED, Buzzer, LCD, vibrator
Dimensions(L x W x H)	164 x 50 x 35(54)mm

Battery Supply

Main Battery	3,200mAH Li-Ion Rechargeable Battery
Power Adapter	Battery Charger(Optional) & DC5V, 800mA

Network Characteristics

Wireless LAN	802.11 b/g/n Wireless LAN, Key Emulator
Bluetooth	Bluetooth 4.0 HID/SPP(BLE Option)
USB	USB 1.1 SPP/HID

Barcode Data Processing Device

Barcode Engine	1D Laser or 2D Image Scanner
----------------	------------------------------



AT388 User guide

AT388 Product User guide

Company

Atid Co., Ltd.

Doc Name

User guide

Writer

Moon-Cheol Song

Date

2017-09-04

Ver.


v0.1

UHF 900MHz RFID Reader/Writer (Option)

Chips set	Impinj R2000 or (R500 option)
Frequency	860~960MHz (Support Global Frequency)
Reading Range	0M~3M(According to Tag & Environment)
Writing Range	0M~1.5M(According to Tag & Environment)
Max. RF output	30dBm, Circular(or Linear type option)
Protocol	EPC Gen2, ISO/IEC 18000-6C
Special Function	Anti-Collision

Accessories


Basic Accessories	Hand Strap, RJ11 Gender, RJ11 to USB Cable
Optional Accessories	AC-DC Adapter, Battery Charger, RJ11 Gender

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

5 Product Composition

5.1 Product Composition

The basic package for AT388 is shown as below



< Device Body >



<Micro USB Cable or RJ-11 to USB Cable>



<Battery>



< RJ11 Conversion Gender >



< Hand strap or Neck strap >




< Charger (option) >




< User Guide >

5.2 Composition of Each Product's Part

i. Front Side




- SCAN Lamp: blue lamp will be lit in case of reading the barcode and RFID Tag information
- Communication State Display Lamp: Show the connection state of Bluetooth, USB, Wireless LAN
- Power Lamp: Show the state-of-charge (Charging : Red, Full Charge : Green)
- LCD Display: Show the collected data and current state of device
- Arrow Button(Left/Right): Movement of Operation Menu or Setting Menu
- Scan Button: Use its button in case of selecting the barcode and RFID Tag

		AT388 User guide					
AT388 Product User guide					Company	Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

reading operation

- Reset Button: Restart the device by force.
- Communication port change Button: Change and selection the Bluetooth, USB, WLAN Communication port
- Cancel Button: Exit the Barcode or RFID Scan operation or Movement of previous Menu
- Power/Selection Button: Power On/Off or Selection of Menu operation

i. Right and Left Side of Device




- RFID Antenna: HF or UHF RFID Antenna are built in the device and, the radio is emitted through RFID Antenna when reading the Tag
- Battery Cover: Battery can be changed after getting rid of cover
- Strap Hole: Fix the Neck strap or Hand strap enclosed with the product

AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

ii. Top and Bottom Side of Device


- RFID Antenna: HF or UHF RFID Antenna are built in the device and, the radio is emitted through RFID Antenna when reading the Tag
- Barcode Module: Barcode scanner is built in the device and 1D or 2D barcode module will be selectively applied. Please note that it should be careful to use since it is one of the most important part to read the barcode
- USB Connector & Waterproof Cover: If the Waterproof Cover opens up, Micro USB connector is located in it. User can charge the device through USB Cable and adapter or can transmit the saved data in the device to PC. Please do lock the cover in case of keeping or using the device.
- Strap Hole: The portability of device can be improved by connecting the Hand Strap or Neck strap with strap hole

iii. Back Side of Device



< Back Side >


- Battery cover: Remove the cover and attach the battery.

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

- Battery Lock: Move the battery lock to the UNLOCK position and the battery cover will open.
- Product Label: This product is labeled with the input voltage and other device information and the serial number of the product.

iv. RJ11 Conversion gender


If you use Gender, you can use a dedicated RJ-11 to USB cable from the Micro USB Connector. Using an RJ-11 cable allows you to maintain a more stable connection when using the Micro USB Cable. If you connect the gender to the USB connector as shown below, you can use the RJ-11 connector.







※ RJ11 to USB Cable compatible with RJ11 Conversion gender can be purchased through the supplier or manufacturer.

Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1
----------	------------	--------	-----------------	------	------------	------	------


5.3 Function of Each Button



- Barcode scan button: Scans the barcode data.
- RFID Scan Button: Scan RFID data.
- ◀ Button: Scroll the screen upward or select the previous item. If user press and hold, the setting menu is displayed.
- ▶ Button: Scroll the screen downward or select the next item.
- Reset Button: Restart the device.
- Communication change Button(): Switch the communication function of USB, Bluetooth, WLAN whenever you press it.
- Cancel Button(): In the Settings menu, cancel the current selection and return to the previous step.
- OK/Power Button(): Select a specific item or press and hold for more than two second to turn the power on and off.


 All That Identification		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

5.4 Configuration and operation of the Lamp



< Display screen and Lamp >


- Communication Status Lamp: Displays the communication method currently in use. Each time the communication switch button is pressed, the three modes of USB (🔌), Bluetooth (📶) and WiFi (📶) are switched, and the lamp of each position lights up.
 Fast blinking: Indicates that it is waiting for connection with host device.
 Slow blinking: Indicates that the host device is connected to the current communication mode.
- SCAN Lamp: According to the setting, the blue lamp lights up when recognizing the barcode or RFID information, and when the data is recognized, the blue lamp also lights up to indicate that normal data has been read.
- Charging lamp: The red lamp lights up when the unit starts charging. Conversely, when the battery is low and needs to be recharged, it blinks. When charging is completed, the blue lamp lights up.

 All That Identification		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

5.5 Screen Composition









AT388 shows the various kinds of item through compact LCD such as the current state of device and read data

The screen is separated as state display section and message display section




5.5.1 State Display Section

Its section shows the present time, battery remains and operating set-up state.

-  Indication of connection mode: Show the USB connection mode () or Bluetooth connection mode () , Wireless Lan connection mode ().
- ? , H , S , T : Show the connection state with the Host.
 Disconnection State(?), HID Mode(H), Serial Mode(S), WLAN (T)
-  : Show the Scanner Mode and show the activated state of Barcode () and RFID () through the ICON.
 (Bright Condition: ON, Dark Condition: OFF)
- 10:00P: Show the set time. (There is a possibility to be different with the present time) It can be reset up at the system configuration menu.
-  Battery State: Show the battery remains as a four level

5.5.2 Message Output Section

Its section shows the read barcode and RFID Tag information.

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

6 Basic Function of Device


AT388 supports the reading function for basic barcode and RFID without host after turning on the device. Please acquire the basic function in accordance with the below step.

6.1 Basic Function of Device

AT388 is basically worked as three kinds of different mode


6.1.1 Scan Mode


This is the screen shown at the first when turning on the device and It acts a role in collecting the barcode and RFID data



6.1.2 Scan configuration Menu


User can adjust the basic setting of device through this menu such as confirmation of read data, memory management, communication mode and setting the time to turn off the device



		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

6.1.3 System Configuration


User can adjust the relation settings with whole function of device, barcode symbol settings, Barcode/RFID operation and communication




6.2 Power ON and OFF

6.2.1 Power ON


- ① Press the Power/Section button for 2 seconds.
- ② After "Booting..." message is come out at the screen, please move the hand from scan in case of that "Wait..." message is come out.
- ③ If the "Scan Ready" message is come out as below, device can read the Barcode or RFID Tag data.



 All That Identification		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1


6.2.2 Power OFF

- ① Press the Power/Selection button for 2 seconds in the Scan Ready
- ② Select the "Yes" through either ◀ button or ▶ button and then, turn off the power by pressing the Power/Selection button
- ③ If "No" is selected, user can return back to the scan mode




6.3 Barcode Data Reading(Barcode Scan)

- ① Press the Barcode scan button in the Scan Ready
- ② User can read the barcode after "Scan Ready" message.




< Scan Ready >




< After Barcode reading >


6.4 RFID Tag Data Reading(RFID Scan)

- ① Press the RFID scan button in the Scan Ready
- ② User can read the RFID tag after "Scan Ready" message.

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1



< Scan Ready >



< After RFID Reading >

6.5 Scan Configuration

Contents for reading history & operation of Barcode/RFID Tag, Auto Power Off might be changed by the scan configuration

Entry for Scan Menu

Please refer to the chapter 5. Settings & Changes in regard to detailed information on scan menu.


- ① Turn on the device
- ② The scan menu will be shown up after pressing the ◀ button for a second
- ③ Select the preferred item by using either ◀ button or ▶ button and then, press the Scan button to check the detailed information on selected item
- ④ Press the "Cancel Button" for returning back to Scan mode

6.6 System Configuration

It has to be controlled in the system configuration menu for changing the operating direction of device, settings for communication function, settings of barcode symbol and scan mode

6.6.1 Entry for System Configuration

- ① Turn on the device
- ② Show the system configuration menu if user press the ◀ button and

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

Power button for several seconds.

- ③ Select the menu by using either ◀button or ▶button and then, enter the configuration menu through scan button
- ④ User can check the detailed information on selected item through the OK button after selecting the preferred item with either ◀button or ▶button in the system configuration menu.
- ⑤ For restarting it to scan mode after completing the whole settings and storing the contents, user has to select the "Save & Exit" after selecting the "8. Exit". If user selects the "No Save & Exit", it will be restarted to scan mode without storage of adjusted contents.

7 Settings & Changes

7.1 Scan Configuration

Please refer to the chapter "7. Settings & Changes in regard to detailed information on system configuration menu

7.1.1 "1. View data"


View Data shows the stored data located in the internal memory, in case of Batch Process Mode. Check the next or previous item through either ◀button or ▶button

7.1.2 "2. Upload data"

Stored data in the internal memory are transferred to Host's USB or Bluetooth or WLAN Data of memory will be remained after transferring.

7.1.3 "3. Erase data"

Stored data in the internal memory can be wholly deleted
If user wants to erase the data, please select "Yes"

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

7.1.4 "4. Data space"


Show the amount of used internal memory



7.1.5 "5. Comm & Mode"

Comm & Mode is set up the communication measures and data transferring way between device and host.


"*" is marked at the present settings.



- ① Realtime-BTH: Transfer the read data to device connected with Bluetooth in real time.
- ② Batch-BTH: Transfer the read data to equipment connected with Bluetooth in a lump (Batch Process mode)
- ③ Remote-BTH: Link with application program. (BTH_SPP only)

7.1.6 "6. Poweroff Time"

The time to automatically turn off the device can be selected as 1 minute, 2 minutes, 5 minutes, 10 minutes, 30 minutes, 60 minutes, 120 minutes, None. The device will be automatically turned off itself after designated time. "*" is marked at the present

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

Settings.



7.1.7 "7.Network Setup"

The menus are organized as follows.

7.1.7.1 "1. Show Info"

Information (SSID, Password) and MAC Address related to WiFi connection set up in this product are displayed. For detailed WiFi connection information setting, please use the special setting tool provided separately.


7.1.7.2 "2. Host Pairing"

When the connection mode is used as Bluetooth or WLAN, it provides a function for pairing with the parent device.

- ① "1. PIN Code": Check pin code necessary for pairing.




- ② "2. WLAN Pairing": Waiting for pairing with host device (HOST) via WiFi, and waits for connection at the host device.

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1




- ③ "3. BTH Pairing": Waiting for pairing with host device (HOST) via Bluetooth, and waits for connection at the host device. The device identification name required for pairing is displayed together.



7.1.7.3 "3. DHCP Mode"



- On: Enable DHCP mode to automatically obtain IP.
- Off: Disable DHCP Mode and set IP on the device separately.

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

7.1.7.4 "4. Paired Mode"



- On: Do not pair with any device other than the last device that was currently paired.
- Off: Allow any device to pair.


7.1.7.5 "5. Manual Setup"

Switch to the mode to receive wireless LAN connection information and IP information from the PC's dedicated setting program.

In this mode, the connection mode is changed to connect to PC through USB - VCP (Virtual Serial Port).

Please refer to the separately distributed manual for setting program for PC.



 All That Identification		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

7.2 System Configuration


7.2.1 "1. Symbol Setup"

User can choose to read the barcode symbol or not. The item that can be set will be changed in accordance with the type and supportive function of module. The "*" is marked at the Enable item.

7.2.2 "2. OP Mode"

Set up the operating mode of RFID and Barcode Reader and basic function of RFID Module

- "1. READER": Set up the barcode and RFID operating mode




"BARCODE": Set up the exclusive barcode mode and, read the only barcode when user pushes the scan button

"UHF RFID": Set up the exclusive RFID mode, read the only UHF RFID Tag when user pushes the scan button.

"BARCORDE-RFID": Set up either barcode mode or RFID mode at the scan ready.

"BARCORDE+RFID": Set up the both barcode mode and RFID mode

- "2. Report Mode":
Set up the tag Reading Mode of RFID among Multi Tag / Single Tag / Multi Repeat

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1




"MULTI": Set up Multi Tag Reading mode to read all the nearby tags.

"SINGLE": Set up Single Tag mode to read only one Tag data.


"Multi Repeat": Set up Multi Repeat mode to read all the tags nearby but does not read same tags twice.

7.2.3 "3. Comm & Mode"

AT188 can connect with host through Bluetooth and USB and WLAN. Both Bluetooth and USB support the different kinds of protocol



- 1. BTH Protocol: Select the communication protocol to be used when connecting with Bluetooth
 - **BTH HID**: It will connect through Human Interface Device and the data to be transferred will be inputted in accordance with the contents typed through Keyboard at the place where the cursor is located. User has to require more attention for using this mode since between the data where the cursor is located and actual reading data can be differently shown up with the keyboard language settings of host.
 - **BTH SPP**: It will connect through serial port profile and the data to be

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

transferred will be transferred to serial port (COM port) of host. The host has to make the separate program for utilizing the transferred data.


- **BLE:** It will connect through Bluetooth Low energy profile and the data to be transferred will be transferred to Keyboard or serial port (COM port) of host. The host has to make the separate program for utilizing the transferred data.


- 2. USB Protocol: Select the communication protocol to be used when connecting with USB

- **USB HID:** It will connect through Human Interface Device and the data to be transferred will be inputted in accordance with the contents typed through Keyboard at the place where the cursor is located. User has to require more attention for using this mode since between the data where the cursor is located and actual reading data can be differently shown up with the keyboard language settings of host.
- **USB VCP:** It will connect through serial port profile and the data to be transferred will be transferred to serial port (COM port) of host. The host has to make the separate program for utilizing the transferred data.

- 3. Com Mode

Set up the data transferring mode and communication protocol between AT388 and host. "*" is marked in selected item.




		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1


- Realtime-BTH: The read data will be transferred to the equipment that connects with its device through Bluetooth in real time
- Batch-BTH: The read data will be transferred to the equipment that connects with its device through Bluetooth (Batch Process mode)
- Remote-BTH: Link with application program. (BTH_SPP only)

7.2.4 "4. Data Format"


The contents of this menu are explained on the basis of a situation that device can read the barcode. The operation can be different when reading the RFID Tag




- "1. Barcode Record": After reading the barcode, user can decide to use the barcode type ID or time to be appended when storing or transferring the data
 "*" is marked in selected item.




- Barcode Only: The only reads barcode data will be stored or transferred
- ID+Barcode: ID of barcode and read barcode data will be stored or transferred

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

- Time+Barcode: Time data and read barcode will be stored or transferred
 - Time+ID+BarcodeMode: Time data, ID of barcode and read barcode data will be stored or transferred.
- "2. Time format": In case of that the time will be stored or transferred with the read barcode, user can set up the time format
 - "*" is marked in selected item





- **Year**: Choose to use the year data or not at the time data (YYYY)
 - **Month & Date**: Choose to use Month & Date or not at the time data(MMDD)
 - **Hour & Minute**: Choose to use Hour & Minute or not at the time data(HHMM)
- "3. Quantity": Choose to input tag quantity. Quantity settings can be operated in the only barcode mode and its settings might be possible after reading the barcode tag. User can get AT188 to input quantity from 1 to 9999 and it cannot read another tag before inputting applicable tag quantity. "*" is marked in default settings
 - "4. Numbering": Store or transfer the data index when reading the barcode and RFID tag. If the memory is vacated, it will be started from 1
 - "5. Terminator": Select which letter will be attached at the end of data among LF, CR, CR&LF, Tab, Space, Semicolon when transferring the data via host

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1


- "6. UHF Report" (**UHF Only**): Select whether only EPC data is sent or both the EPC data and PC data is sent when transferring the UHF RFID Tag Data

7.2.5 "5. System Setup"


Set up to use the time, sound, vibrator, LCD and etc are needed or not




- "1. Clock Setting": Set up the current time. Designated time can be used with RFID tag information and barcode.
★ Please do set up the time in regularly since time error can be occurred
- "2. Poweroff Time": Select the time to automatically turn off the power when not in use. User can select the time among 1 minute, 2 minutes, 5 minutes, 10 minutes, 30 minutes, 60 minutes, 120 minutes and None. The device will be automatically turned off the its power after the designated time from LCD power off. "*" is marked in default settings



- "3. Disp,off Time": Set up the time to turn off the LCD for saving battery and LCD will be automatically turned off in accordance with the designated time

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1



- "4. HID Language": Set up the language type in case of HID mode. User can select the preferred one among the UNIVER-SAL, FRENCH, UK, US
- "5. Notification": Set up the operation when pressing the button or placing the Alert situation
 - 1. Button notify
Set up whether beep, vibrate, light is being operated when pressing the button.
 - 2. Alert notify
Set up whether beep, vibrate, light is being operated when placing the Alert situation such as connection success/failure with remote or booting up. The time to operate can be different in accordance with situation
 - 3. Button mode
Select the holding time of Button notify among None, Short, Long. In case of None settings, there is no reaction, but in case of Short settings, it will operate for 0.3 seconds. In case of Long settings, it will operate until user detaches the button
- "6. BT HID Mode": Set up the Bluetooth HID data speed to High or Low speed.
 - High Speed
Set up the Bluetooth HID data speed to High speed.
 - Low Speed
Set up the Bluetooth HID data speed to Low speed.

		AT388 User guide					
AT388 Product User guide					Company	Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1


- "7. F/W Version": Show the installed firmware version. User cannot change the firmware for changing the basic function and improvement of device. Please make an inquiry on the firmware to manufacturer or distributor.

7.2.6 "6. Factory Reset"

Return all settings to default

7.2.7 "7. Exit"

Terminate the system configuration and saving operation.

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

8 WiFi Connection and Setup

This product can transmit data to host device such as PC through Wireless LAN (WiFi). This chapter guides you through setting up the SSID and transferring data via WiFi to transfer data via WiFi.


8.1 Preparations

The following program is required for WiFi connection of this product. The program can be obtained from the manufacturer or sales agent.


- ① program: AT388 PC Agent Program Install package
- ② AT388 product
- ③ USB Cable or RJ11 to USB Cable
- ④ A computer with Windows 7 (8) or Windows 10 with WiFi enabled

8.2 WiFi SSID and Password Setup


- ① When the PC Agent program is installed on the PC, the AT388 PC Config Utility and Agent shortcut are automatically created on the desktop.



- ② Turn on AT388 and go to 7.Network Setup -> 7. Manual Setup. menu
- ③ Connect RJ11 to USB or USB Cable to AT388.
The PC will automatically install the USB driver.
(If the USB driver does not install properly, please contact the manufacturer or the supplier.)
- ④ Run the AT388 PC Config Utility.




- ⑤ Click the item of the serial port (P), select the item marked "AT91 USB to Serial Converter (COMxx)" and click the connection.




- ※ The numbers after COM may change according to your PC environment.
- ※ If the Port like the one shown in the figure is not displayed, please try again by pressing the Rescan button (R) and check the Driver installation status.


- ⑥ Click the Search (S) button to search for available SSIDs.



- ⑦ If you double-click one of the SSIDs displayed in the List, the corresponding SSID is automatically displayed in the SSID field. After entering the connection password, click the setup (W) button to transfer the information to AT388.



- ※ The SSID displayed here is the SSID retrieved from the PC and may differ from the actual SSID that AT388 can access.
- ※ For Access points that are not broadcasted or that use SSIDs that are not

 Atid <small>All That Identification</small>		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

searched in this preference pane, you can enter the SSID directly.

- ⑧ DHCP를 For a network that does not use DHCP, you can enter the static IP and press the Setup (P) button to transfer the information to AT388.
- ※ If the DHCP setting is OFF, you can use the IP information you set yourself. If the DHCP setting is ON, the IP information you set will not be used.


8.3 Verifying the Data Transfer using WiFi

This product's AT388 PC Agent allows you to automatically enter data at the current cursor position or receive data directly from the homepage. This setting may require knowledge of the wireless network. Please work with someone familiar with the terminology used and your wireless network.


- ① Start by selecting the operation mode of AT388.
- ② Switch to WLAN connection mode with communication switch button.
- ③ If the AP is connected to the AP set while holding down the Cancel (C) button after about 1 minute, the SSID and the assigned IP information are displayed.
- ④ Check the AT388 is connected to the same network as the PC.
- ⑤ Run AT388 PC Agent on the PC. When the program is executed, an




icon will be displayed in Tray ICON on the lower right side of Windows.




- ⑥ Right-click the AT388 PC Agent ICON, and then click Settings (O) in the menu that appears.


		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1




- ⑦ Click Set (O) to enter the IP address of the AT388 to be connected, or click AT388 (S) button to select AT388 and press the OK button to finish the setting.



- ※ Port number is 3000 is the default.
 - ※ Certification number (A) means pin code, default value is 1234. AT388's 7. Network Setup -> 2. Host Paring -> 1. Pin code menu can be view and checked.
- ⑧ AT388 PC Agent Click the right mouse button on the ICON and click Connect (C) in the menu that appears. The AT388 will beep twice shortly and connect to the PC. If the connection is successful, the AT388's shape changes to "T".
- ⑨ In this state, when the barcode or RFID tag is recognized, the

		AT388 User guide					
AT388 Product User guide					Company	Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

corresponding data is recorded at the position of the current cursor on the PC. (If you checked "Transfer data to keyboard emulator (K)" in option (O)),

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1


9 Bluetooth Connection setting

To transmit / receive data using this product with Bluetooth, you need a PC with built-in Bluetooth function or a dedicated Bluetooth dongle.


- ※ Please check with your PC vendor or product installer for details on Bluetooth function.
- ※ This chapter assumes that the Bluetooth driver is installed normally.
- ※ Please contact the distributor or the manufacturer who purchased the product for any problems during use or installation.
- ※ If the Bluetooth driver does not install properly, or if you use a special driver that is supported separately by Windows 7 and 8 or 10 OS, this manual and the contents may not match.

9.1 Windows 7 Environment


- ① Turn on the AT388 and set it to 7. Network Setup -> 2. Host Paring -> 3. BTH Pairing.
- ② In Windows, select Start -> Control Panel -> Hardware and Sound -> Devices and Printers -> "Add Bluetooth Device".



- ③ The Bluetooth device will be detected automatically, select the AT388 you want to connect to, then press N (Next) to proceed with device

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1


addition.




- ④ When the confirmation window for the connection code is displayed, press N to continue. The connection code does not need to be changed specially.



- ⑤ After a while, Windows7 will automatically detect the driver and proceed with the installation, and the screen will display the message Completion of device addition.


 Atid <small>All That Identification</small>		AT388 User guide					
AT388 Product User guide					Company	Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1




- ⑥ Double-click on the newly added AT388 in Control Panel -> Devices and Printers to display its properties, then go to the "Services" tab.




 Atid <small>All That Identification</small>		AT388 User guide					
AT388 Product User guide				Company	Atid Co., Ltd.		
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1



- ⑦ After checking all the two services that appear in the Bluetooth service, click the OK button to finish adding the service and adding the Bluetooth device.




- ⑧ After that, exit the setting menu of AT388 and set it to the desired operation mode.

		AT388 User guide					
AT388 Product User guide					Company	Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

9.2 Windows 8 or Windows 10 Environment


Windows 8 and Windows 10 are similar to the basic user interface, so the contents are based on Windows 8.

- ① Turn on the AT388 and set it to 7. Network Setup -> 2. Host Paring -> 3. BTH Pairing.
- ② In Windows, select Start -> PC Settings -> PC and Devices -> Bluetooth.



< Select settings at Start >


->




< Select Bluetooth on your PC and device >

- ③ If Bluetooth is off, if you change Bluetooth to on, the AT388 is automatically detected and displayed.

※ The AT388 name may take a while to appear.




- ④ After confirming that the displayed contents of the AT388 matches the

 Atid <small>All That Identification</small>		AT388 User guide					
AT388 Product User guide					Company	Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

AT388's LCD screen, click the "Connect" button on the corresponding device.


- ⑤ When the device connection is established for the first time, the password (PIN code) with AT388 will be set automatically, and if confirmation screen is displayed, click "Yes".

※ The password is set automatically, so there is no need to change it.




- ⑥ The driver will be installed automatically when "Connect" is done.


※ It may take a few minutes to install the driver.




- ⑦ After the driver installation is complete, the message "Paired" is

 Atid <small>All That Identification</small>		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

displayed when the device is successfully added.



- ⑧ After that, exit the setting menu of AT388 and set it to the desired operation mode, then use it.

 Atid <small>All That Identification</small>		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

10 Firmware Update


Firmware for AT388 can be updated for improvement of its device. If user does not have a proper knowledge on software and hardware, please ask distributor or manufacturer to handle the issue since the recovery of device cannot be possible, in case of that the problem comes up in doing update.


10.1 Preparation for Firmware

- Computer with over Windows 7 OS
- 1 piece of USB 2.0 Port
- AT388 product
- Micro USB Cable (with Device sold)
- Firmware File(.bin)
- Firmware Updater Application
(SetupUpdater.msi, it will be supplied from manufacturer or distributor)


10.2 Firmware Update Start

- ① Install the SetupUpdater.msi into the PC (With Double-click)
- ② Save the Firmware File to specific folder
- ③ Execute the Firmware Update Program(fwupdate.exe)



		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1


- ④ Click the "Load Binary File" button and then, select the stored Firmware File in the specific folder



- ⑤ Connect AT388 with PC through USB cable




- ⑥ Enter the the Firmware Download Mode in AT388's configuration menu.




		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1




- ⑦ Click "select comport" in the Updater and select the assigned COM port




- ⑧ "Online" will be appeared when clicking "off line" and Firmware version will be displayed as well.




		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

- ⑨ Start the download for Firmware by clicking the download button



- ⑩ After completion of download, new firmware will be automatically restarted

		AT388 User guide					
AT388 Product User guide				Company		Atid Co., Ltd.	
Doc Name	User guide	Writer	Moon-Cheol Song	Date	2017-09-04	Ver.	v0.1

11 Warranty and Technical Supports

All of ATID products have one-year warranty from date of manufacture

However, there is a principle in ATID that the customer will be charged for the repairs, in case of the damage caused by customer even if it is under warranty period

We recommend requesting the warranty and technical support for AT188 through distributor.

ATID Co., Ltd.

#1211 Byuksan/Gyungin Digital Valley II, #481-10 Gasan-Dong Gumchon-Gu, Seoul, Korea

TEL: +82-2-544-1436

FAX: +82-2-2113-0040

Homepage: <http://www.atid1.com>

E-mail: atid@atid1.com , webmaster@atid1.com

English: +82-70-8677-8589

Chinese: +82-70-8677-8669

Japanese: +82-70-8677-8594

Korean: +82-70-8677-8594